I'm not a bot

How to change belt on kenmore vacuum model 116

How to change the belt on a kenmore vacuum cleaner model 116. How to change a belt on a kenmore vacuum cleaner. Replace belt kenmore vacuum model 116.

How to Mend a Powerwasher PRO PRO1800PWE and Replace the Power Cord? To repair your Powerwasher PRO PRO1800PWE, start by identifying the number of screws holding the handle in place. It's likely that you've already removed some screws; remove any additional screws until you can access the switch on the handle. If you're having trouble finding loose wires, lift up the cover to inspect for any issues. #### Additional Tips and Reminders For those familiar with the 116 Hepa model, removing only two screws will allow you to access the tabs and pull out the cover. Be cautious when lifting it up as the tabs may be difficult to see due to their matching color. Remember that replacing the drive belt on your Kenmore model 116 requires sliding open the latchs, releasing the loops attached to the rubber bumper edges, pinching two clips at the back of the cover, and lifting it up while rotating it forward. After removing the roller, reinsert the pieces that hold it in place with their flat edges facing upwards. When placing the new belt around the drive axle and movable selector roller, ensure it's correctly lined up and insert the end pieces into their slots. You may need additional hands to hold the housing unit during this process, as it can be a challenging stretch. A contractor with over 40 years of experience finally figured it out after struggling for a while. The solution was found on this website and took mere seconds to implement. A grateful "Big daddy" expressed thanks for the timely help. Another user, Sandy Brady, was in a bind when their sweeper's cord got tangled with a window blind cord. They were relieved to find the suggested solution and are now prepared for future roller maintenance. Jim from Chicago thanked Andrew for providing an answer that not only helped him but also ended his three-day struggle with the machine. In a similar vein, "Grateful me" was overjoyed to have successfully vacuumed their floor after following Andrew's instructions. The key was realizing that the top cover of the sweeper unit is separate from the light cover. Andrew shared his experience and provided step-by-step instructions for replacing the belt on a Kenmore sweeper. This included removing screws, prying open tabs, and lifting out the roller brush. There were also questions about mending a Powerwasher PRO PRO1800PWE, replacing its power cord, and troubleshooting an unresponsive switch on the handle. Users such as Eddie and Brenda sought advice and received helpful responses that guided them through their repair challenges. 1. remove front cover slide latchs outward 2. remove light/agitator cover release small loops attached rubber bumper edges pinch two clips back attach lift forward 3. pull rubber bumper edges away ends roller lift roller straight up pieces hold roller ends slide up slots 4. difficult see until roller lifted notice piece each slot flat edge up reinsert with this orientation fully remove roller 5. belt placement order reversed roller drive axle but tight spaces sharp edges next belt 6. agitator selector lever "carpet" position place good belt drive axle also movable selector roller rear housing stretch belt position roller pull forward line up insert end pieces slots 7. hard stretch belt entire housing unit need held place make stretch check belt turning freely lined up roller drive axle I've come across similar issues with Kenmore machines, where their assembly seems almost intentionally complex. A user from Chicago in '08 experienced the same struggle and was grateful for Andrew's solution that also resolved my query. It's amusing how happy someone can be to vacuum after finally resolving an issue! In a similar situation, I didn't have a manual either, but with some experimentation, here's what worked: the top cover is deceptive as it looks like one piece of plastic, but in reality, it consists of two parts - the light cover being removable separately. It's wise to take out the bulb to avoid any damage when taking off or putting back the main cover. This reveals two screws that need removal. Turning the unit upside down shows little tabs on either side; they say "use a screwdriver to pry" - use this hint and you'll find that sliding a straight screwdriver between the body and outer cover will help lift the body out of its cover on both sides. Once these tabs are free, turn it over again and take off the outer cover. After that, the roller brush can be removed to replace the belt. Andrew shared his solution in December '07.